

<b>SUBJECT</b>	<b>PAGE NO.</b>
7.1 Specifications .....	7-1
7.2 Ignition System .....	7-3
7.3 Diagnostic Charts .....	7-6
7.4 Throttle Position Sensor (TP Sensor) .....	7-12
7.5 Bank Angle Sensor .....	7-13
7.6 Ignition/Headlamp Key Switch .....	7-14
7.7 Auto-Enrichener .....	7-16
7.8 Ignition Module and Cam Position Sensor .....	7-18
7.9 Ignition Coil .....	7-23
7.10 Spark Plug Cables .....	7-25
7.11 Starter/Ignition Interlock .....	7-26
7.12 Diodes .....	7-33
7.13 Charging System .....	7-34
7.14 Alternator .....	7-40
7.15 Voltage Regulator .....	7-43
7.16 Battery .....	7-44
7.17 Headlamp .....	7-49
7.18 Tail Lamp .....	7-51
7.19 Turn Signals .....	7-52
7.20 Turn Signal Flasher .....	7-54
7.21 Handlebar Switches .....	7-55
7.22 Horn .....	7-57
7.23 Neutral Indicator Switch .....	7-58
7.24 Fuses And Circuit Breakers .....	7-59
7.25 Electronic Speedometer .....	7-60
7.26 Speedometer Sensor .....	7-62
7.27 Speedometer Performance Check .....	7-63
7.28 Indicators .....	7-68
7.29 Main Wiring Harness .....	7-69

