

Table Of Contents

| SUBJECT | PAGE NO. |
|-------------------------------------------------|-----------------|
| 7.1 Specifications | 7-1 |
| 7.2 Ignition System | 7-3 |
| 7.3 Ignition/Headlight Key Switch | 7-5 |
| 7.4 Spark Plug Cables | 7-10 |
| 7.5 Starter Interlock | 7-12 |
| 7.6 Interactive Exhaust System (XB12S) | 7-19 |
| 7.7 Charging System | 7-23 |
| 7.8 Alternator | 7-30 |
| 7.9 Voltage Regulator | 7-32 |
| 7.10 Battery Cables | 7-33 |
| 7.11 Battery | 7-35 |
| 7.12 Headlight | 7-42 |
| 7.13 Tail Lamp | 7-45 |
| 7.14 License Plate Lamp Assembly | 7-46 |
| 7.15 Turn Signals | 7-47 |
| 7.16 Turn Signal Flasher | 7-50 |
| 7.17 Handlebar Switches | 7-51 |
| 7.18 Speedometer Sensor | 7-54 |
| 7.19 Instrument Module | 7-55 |
| 7.20 Speedometer Performance Check | 7-56 |
| 7.21 Horn | 7-61 |
| 7.22 Neutral Indicator Switch | 7-63 |
| 7.23 Main Fuse and Fuses | 7-64 |
| 7.24 Main Wire Harness | 7-65 |
| 7.25 Interactive Exhaust Actuator Harness | 7-72 |
| 7.26 Sprocket Cover Wiring | 7-74 |

