

b1114xaxf




Figure D-1. Front and Rear Brake Systems, Right Side View

b1115abxf




Figure D-2. Rear Brake Systems, Top View

b1116acxf




Figure D-3. Rear Brake Systems, Left Side View

b1117aaxf





Figure D-4. Evaporative Emissions Control, California Models, Top View

b1118abxf




- 1. To induction module
- 2. From induction module (California)

- 3. From fuel tank (California)
- 4. From fuel tank to atmosphere (49 state)

Figure D-5. Evaporative Emissions Control, California and 49 State Models, Left Side View

b1119xcxf




- 1. Active intake solenoid (Japan only)
- 2. Intake air temperature sensor (IAT)

- 3. Fuel pump

Figure D-6. Wiring Harness, Left Side View

b1120abxf



- 1. Fuel injector (2)
- 2. Throttle position sensor (TPS)

- 3. Intake air temperature (IAT) sensor
- 4. Oxygen (O2) sensor

Figure D-7. Wiring Harness, Top View

b1121xdsxu





Figure D-8. Wiring Harness, Right Side View

b1122xbsxf




1. Vent line
2. Feed oil line
3. Return oil line

4. Feed oil line from the oil pump to the oil cooler
5. Return oil line from the oil cooler to the oil filter housing

Figure D-9. Oil Lines, Right Side View

b1123xcxf



1. Vent line

2. Feed oil line

3. Return oil line

Figure D-10. Oil Lines, Bottom View

b1124xbxf




Figure D-11. Clutch, Throttle Cables and Interactive Exhaust System (1200 Only), Right Side View

b1125xcxaf




Figure D-12. Clutch, Throttle Seat Release Cables and Interactive Exhaust System (1200 Only), Left Side View

b1126xdxaf




Figure D-13. Clutch, Throttle Seat Release Cables and Active Intake System with Exhaust Valve Actuator (1200 Only), Top View

